





RULER FOOT LOW SHANK	
Brand	Model
Bernette®	A series (model Milan 2, Milan 3, Milan, 5 Milan 7, Milan 8, Moscow 2, Moscow 3, Moscow 5, Moscow 7, Moscow 8, Rome 3, Rome 5, Rome 7, Rome 8)
	B series (model London 2, London 3, London 5, London 7, London 8)
	C series (model Chicago 5, Chicago 7)
	D series (model 340 Deco, 340 Deco Plus)
	E series (model Sew&Go 1, Sew&Go 3, Sew&Go 5, Sew&Go 7, Sew&Go 8)
	F series (model B30, B33, B35, B38)
	Sew Pink
brother®	AE series (model 1700, 2500, 2700)
	AS series (model 40)
	AZ series (model 14, 17)
	BB series (model 370)
	BC series (model 2100/2300, 2100PRW, 2500)
	BM series (model 2700, 2800, 3600, 3500/2600, 3600/2700, 3700, 3850)
	BX series (model 2925PRW, 3000)
	CE series (model 1008, 1100PRW, 1125PRW, 4000, 4400, 5000, 5000PRW, 5100, 5500, 5500PRW, 7070PRW, 8080, 8080PRW, 8100)
	CP series (model 6500, 7500)
	CS series (model 10, 100T, 4000, 5000, 5055PRW, 6000, 6000b, 6000i, 6000t, 70, 7130, 7205, 80, 8060, 8072, 8120, 8150, 8200, 8800PRW, 9100)
	CX series (model 155LA, 205LA, 310LA)
	DS series (model 120, 140)
	ES series (model 2000, 2000T)
	EX series (model 660)
	FB series (model 1757T)
	FS series (model 100WT, 101, 130QC, 155, 20, 210, 40, 40WT, 50, 60, 70WT)
	GS series (model 2500, 2510, 2520, 2700, 3700, 3710)
	GX series (model 37)
	HC series (model 14, 1800)
	HE series (model 240)
	HF series (model 27, 37)
	HS series (model 2000, 2500, 3000)
	Innov-is series (model 10, 10A, 1000, 1200, 1250, 1250D, 15, 150, 150SE, 1500, 1500D, 20/20LE, 200, 200QE, 210, 2200, 27SE, 30, 35, 350SE, 400, 40, 40E, 4000, 4000D, 410, 4500D, 4750D, 50, 500D, 55, 550SE, 550, 55FE, 5000, 600, 610, 6000D, 6700D, 6750D, 80, 85E, 900, 900D, 950, 950D, 955, 97E, 980D, 990D, I, Ie,
	Innov-is series B (model BM3500D)
	Innov-is F series (model F400, F410, F420, F440E, F460, F480)
	Innov-is M series (model 280D)
	Innov-is NQ series (model 1300PRW, 1300, 1400E, 1600E, 3500D, 3600D, 550PRW, 575PRW, 700PRW, 900PRW)
	Innov-is NS series (model 1750D, 2750D)
	Innov-is NV series (1100, 1300, 1800Q, 2600)
	Innov-is VM series (model 5100, 6200D)
	Innov-is VQ series (model 2400, 3000)
	Innov-is V series (model V3)
	Innov-is XV series (model 8500D, 8550D)
	J series (model 14, 14s, 17, 17s)
	JK series (model 1700, 2500NT, 2700NT, 4000, 7000)
	JS series (model 1400, 1410, 1420, 1700, 2135, 23, 60)
	JX series (model 2517, 3135F)
	KD series (model 144, 144S)



KE series (model 14, 14s)
L series (model 14, 17)
LB series (model 6770, 6770PRW, 6800, 7000)
LK series (model 14)
LS series (model 1217, 14, 17, 1717, 2000, 2020, 2125, 2129, 2130, 2150, 2160, 2250PRW, 2300PRW, 2320, 2350, 2400, 2720, 2725, 2775, 2820, 2825, 2920, 30, 3125, 400, 590)
LX series (model 17, 1700, 2375, 25, 2500, 27NT, 2763, 3014, 3125, 3125E, 37NT, 3817, 3850)
NS series (model 10, 20, 25, 30, 30LE, 35, 50, 55)
NX series (model 200, 200QE, 2000, 250, 400, 400Q, 450, 450Q, 570Q, 600, 650Q, 800)
PC series (model 1750, 1950, 210, 210PRW, 2300, 24, 2500, 2800, 3000, 4000, 420, 420PRW, 5000, 6000, 6500, 660LA, 7000, 7500, 8000, 8500, 8500D, 8896)
PS series (model 1000, 1200, 1250, 1700, 1750, 1800, 1900, 1950, 21, 2100, 2150, 2200, 2250, 2300, 2360, 2400, 2470, 2500, 31, 3100, 33, 35, 3700, 40, 53, 55, 57)
QC series (model 1000, 2000)
RH series (model 127, 137)
RL series (model 417, 425)
SB series (model 170, 3129, 3734T, 4138, 530T, 700T, 7050E, 7500, 7900E, 8000)
SC series (model 3000, 6600, 707, 9500)
SE series (model 1800, 1900, 270D, 350, 400, 425, 600, 625)
SL series (model 100, 300, 500)
SM series (model 1400, 1704, 1738D, 2700, 3701, 6500PRW, 8270)
SQ series (model 9000, 9050, 9185, 9285, 9310)
ST series (model 371HD, 4031D, 531D)
STAR series (model 110, 130E, 230E, 240E)
UJ series (model 417)
VX series (model 1005, 1010, 1020, 1040, 1060, 1080, 1090, 1100, 1111, 1120, 1125, 1140, 1145, 1200, 1250, 1400, 1435, 1445, 1500, 2010, 2020, 2061, 2080, 3240, 3250F, 520, 540, 560, 566, 620, 640, 660, 700, 707, 710, 720, 757, 760, 780, 790, 800, 802, 807, 808, 809, 810, 847, 857, 860, 870, 880, 883, 890, 900, 920, 940, 970, 980)
X series (model 14, 14S, 17, 17S)
XL series (model 1001, 114, 1351, 1561, 1781, 1950, 200, 2000, 2001, 2005, 2015, 2021, 2022, 2025, 2027, 2030, 2120, 2130, 2220, 2230, 2240, 2600, 2600i, 2610, 2620, 2630, 2800, 300, 3000, 3010, 3022, 3025, 3027, 3030, 3100, 3200, 350, 3500, 3500i, 3500T, 3510, 3520, 3600, 3700, 3750, 4001, 4010, 4012, 4013, 4014, 4015, 4020, 4030, 4040, 4050, 4060, 461, 471, 50, 5000, 5001, 5010, 5011, 5012, 5020, 5021, 5030, 5031, 5050, 5060, 5070, 5100, 5130, 5132, 5200, 5232, 5340, 5500, 5600, 5600i, 5700, 6452, 6462, 6552, 6562, 700, 703, 711, 771, 781, 791, 795, 8005, 851)
XM series (model 1010, 2701, 3700)
XN series (model 1700, 2500)
XR series (model 1300, 1355, 16, 21, 23, 27, 29, 31, 3140, 32, 3240, 33, 34, 37, 3774, 40, 4040, 46, 46C, 52, 52C, 53, 55, 6060, 65, 65T, 6500, 7700, 9000, 9500PRW)
XS series (model 2070, 2080, 2100, 3109, 37)
XQ series (model 2700, 3700)
XT series (model 27, 37)
with adapter "S" - SA131, F010N, XA6126-002, XA6126001, #XA6027001 - Super ACE +e, PC6500, PC8200, PC8500, PC8500D, Super Galaxie 2000, Super Galaxie 2100, Super Galaxie 2100D, Super Galaxie 3100, ULT2001, ULT2002D, ULT2003D, Innov-is V5, Innov-is V7, VM5100, VM6200D, VQ2, VQ2400, VQ3000, XV8500D, Innov-is 2800D, Innov-is 2500D, Innov-is 1500D, PE8500

	<p>Sew Green, Sew Fun, Sew Zebra, Sew 75, En Vision CE20, 2002, 2004, 2006, 2110, 2130, 2600 BLUE, 2800 BLUE, 3003, 3005, 3007, 3008, 3210, 3230, 5000, 5100, 6000, 6001, 6003Q, 6004, 6005, 7000, 7200 PRO, 8000, eXplore 150, 160, 220, 240, 320, 340, Lotus 2, eXperience 520, 540, 550, 560. 570, 580, 620</p>
	<p>5 group (model Emerald 116, 118, 122, Prelude 340, 360, 350, 370 Prelude, Scandinavia 100, Daisy 335, 330, 325, 320, 315, 310, Oscar, Sophia, Emma, Lena, Romeo, Juliet, Anna, Sarah, 250, 230, 225/215, 210, 205, Jeans, Hugin, Tribute 145M)</p>
	<p>6 group (model Platinum 955 E, 950 E, Platinum Plus, Platinum 770, 775, Platinum 750 Quilt, 755 Quilt, 350, Platinum 730, 735, Platinum 715, Rose 600, 605, Iris, 400 Computer, Scandinavia 400, 300, 200, Interlude 445, 435, Lily 555, 550, 545, 540, 535, 530, 500, Freesia 445, 435, 425, 415, Lisa, Angelica, Viva, Victoria, 500, Facette 500/400, Emerald 122, 203, 183)</p>
	<p>7 group (model Brilliance 75Q, Designer Brilliance 80, Designer SE, Designer I USB, Designer I ESS, Designer I, Designer II, Designer Diamond, Designer Jade 35, Designer Diamond Royale, Designer Ruby, Designer Ruby deLuxe, Designer Ruby Royale, Designer Topaz 20, Designer Topaz 30, Designer Topaz 40, Designer Topaz 50, Designer SE Limited Edition, Eden Rose 250C, Opal 690Q, Opal 670, Quilt Designer, Quilt Designer II, Sapphire 875Q, Sapphire 875, Sapphire 870, Sapphire 855, Sapphire 850, Sapphire 835, Sapphire 830, Sapphire 930, Sapphire 960Q, Tribute 140C)</p>
	<p>8 group (model Designer Epic 980Q)</p>
	<p>Old style model (1017 Harmony, 601, 602, 632, 623N, 623R, 635C, 636, 637, 639 Jem (Argos 555) 641, 648, 649, 653, 667, 668, 672, 674, 678, 680, 690, 691, 692, 693, 696, MK2, MK5 MK8, MK12)</p>
	<p>Caregory A (model 100-110, 1000CS, 1004, 1012A, 1014, 1018S, 1220, 1308, 1312, 1406, 1408, 1410, 1504, 1508, 1512, 1550, 1560, 1571, 1580, 1585, 1714, 1722, 1780, 1804, 1814, 1818, 1822, 1918, 2015s, 2015a, 2023, 2032, 2039, 2041, 2050, 2060, 2070, 2080, 2090, 2139, 2200XT, 2300XT, 300-372, 3300, 3816, 3822, 4400, 415, 419s, 423s, 609, 620, 623, 626 628, 655, 656a, 656b, 657, 657a, 660, 808, CJ14, CJ24, COMBI, COMBI-10, DM21, DE25, DE1800, ENX24, ES14N, J1012, J1024, J3-18, J3-20, J3-24, M50QDC, M100QDC, NOV3000, NOV4000, RX18S, SIMPLICITY, S2600, XLII, 813, LSM100, LSM200, SMD110, SMD500, SMD1000, XR-23, PS1024, PS1030, RE1318, DM1000, DM1118, DM1018, DM1108, DM1800, DMX200, DMX300 LX180, John Lewis JL110, Decor Excel DEX 20 & 25, JL100, JL125, JL200, J1024, JR1012, JL110, JL110SE, JL170)</p>
	<p>Category B (model MC5600P, MC3000, MC3500, MC4000, MC4800, MC4800QC, MC5000, MC5200, MC5500, MC6000, MC6500P, MC7000, MC7500, MC4900QC, MC5200, MC5900QC, DC3050, DC4030, DC4100, DC3050, 6019QC, 6260QC, 6125QC, JEM GOLD, JEM GOLD2, DKS30 XL30, XR33, XC33, XC50, 150, 2014, 2018, 2022, 2100, 2122, 2522LE, 2536, 3015, 3018, 3023, 23L, CXL301, 3123, 23X, 4018, 4023, 4035, 4052, 4618, 4623, 5018, 5050, 5024, 5060DC, 5124, 521, 525s, XL601, DXL603, QXL605, TXL607, 625E, 652, 654, 658, 659, QXL605, 7021, 7025, 8050XL, 8077, 826, BCC-30, CC500, CC1000, CM2200, CMX30, COMBI DX, CP5000PRO, DC4030, DC4100, DKS30, DKS100, DM200, DM300, DM3000, DM2000, JEM PLATINUM, JP720, JP760, JUBILEE 85, K150, M7, RE3000, SL30X, SR2000, CREATE, STYLE, CXL301, HD2200, MXL50, MY Excel 15S, MY Excel 18W, MY Excel 23X, MY Excel 23L, MY Style 16/652, MY Style 21/658, MY Style 30/654, MY Style 22, SMD2000, SMD3000, SMD4000, SMD5124, SMD5018, LSM300, LSM400, LSM400Q, 5000Q, John Lewis Decor Excel 30& HD Excel 5025, JL150, JL250, JL300C, JL300, JL330, JLX2000, DEXHD, DEX30)</p>
	<p>70HW-A, 80HP-A, 353ZR-C, 355ZW-A DX series HZL (model DX5, DX7) F series HZL (model F300, F400, F600) G series HZL (model G120, G220) LB series HZL (model 5020, 5100)</p>

PFAFF

1000, 1006, 1007, 1019, 1025, 1027, 1030, 1035, 1047, 1050, 1051, 1067, 1069, 1071, 1100, 1132, 1142, 1147, 1150, 1151, 1171, 130, 1300, 1371, 139, 1410, 1411, 1418, 1422, 1445, 1446, 1455, 1465, 1467, 1469, 1471, 1472, 1473, 1475, 1520, 1522, 1524, 1525, 1527, 1532, 1534, 1542, 1546, 2010, 2022, 2024, 2025, 2026, 2027, 2029, 2030, 2032, 2034, 2036, 2040, 2042, 2044, 2046, 2048, 2054, 2144, 2274, 230, 296, 350, 382, 422, 6000, 6085, 6091, 6110, 6112, 6120, 6122, 6130, 6230, 6232, 6250, 6252, 6270, 7000, 7510, 7530, 7550, 7560, 7562, 7570, 800, 801, 802, 803, 806, 807, 808, 809, 874, 875, 876, 900, 904, 905, 907, 917, 919, 927, 933, 939, 946, 947, 953, 955

Hobby series (1020, 1022, 1030, 1032, 1040, 1042, 4240, 4250, 4260)

Select series (1478, 1530, 1536, 1538, 1540, 2.0, 3.0, 3.2, 4.0, 4.2)

Crearive series (2124, 2134, 2140, Icon)

Tiptronic series (2020, 6150, 6152)

Smarter series (140s, 160s, 260c)

Expression series (2028, 720)

Performance series (2056, 2058, 5.2, Icon)

Quilt Ambition series (155, 1.0, 1.5, 2.0, Essential)

Inspiration series (4210, 4220, 4228)

Futura series (100, 200, 6010, 9000)

Merritt series (1872, 1873, 2517, 2108, 3014, 3130, 3145, 3314, 3317, 4525, 4526, 4528, 4530, 4538, 6021)

Fasion Mate series (14C, 17, 22C, 237, 248, 257, 288, 360, 362, 7256)

Millennium series (6408, 6412, 6416, 6423,

Tradition series (2250, 2259, 2277,

Scholastic series (5511, 5523, 6510, 8280)

Confidence series (7463, 7467, 7467S, 7469Q, 7470)

1019, 1021, 1022, 1025, 1027, 1103, 1105, 1106, 1108, 1116, 1120, 1130, 1200-1, 1247N, 1260, 1263N, 127, 127-12, 127-3 Vibrating Shuttle, 128, 1280N, 1288N, 132Q
FEATHERWEIGHT®, 13400, 1409 Promise, 15 Class, 15-125, 15-30, 15-86, 15-87, 15-88, 15-90, 15-91, 15-96, 15-97, 1500 Izek, 1507WC, 1525, 1725, 185, **1800 series** (1800, 1802, 1803, 1812, 1852, 1862)

2020, 2102, 2105, 2106, 2010 Superb, 2110, 2112, 2114, 2118, 2202, 2263 Simple, 2273 Esteem II, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 2600, 2601, 2602, 2603, 2604, 2605, 2615, 2616, 2623, 2628, 2630, 2638, 2643, 2662, 27 Vibrating Shuttle, 2732, 2932, 293B, **200 series** (200, 201, 201-2, 202, 203, 204, 205, 206, 206K, 207, 208, 209, 210, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221 FEATHERWEIGHT®, 221 Quilter, 222, 223, 224, 227, 228, 237, 239, 240, 242, 244, 247, 247AP, 250, 252, 254, 258, 259, 263), **2500 series** (2500, 2503, 2504, 2515, 2530, 2543)

3001, 3002, 3003, 3004, 3005, 3006, 3007, 3008, 3009, 3010, 3011, 3012, 3013, 3015, 302, 30215, 30218, 305, 30518, 306K, 306K25, 306W, 320, 3207, 3208, 3214, 3215, 322, 3221 Talent, 324 Prelude, 3270, 327, 327K, 328K, 28K, Style-O-Matic, 329K, 330, 3302, 3305, 3311, 3343, 337, 338, 340, 342, 345, 347K, 348K, 350, 350 Series, 353 Genie, 354 Genie, 360 Series, 367, 3800, 3810, 3820, 3825, 384 Sears Model, 384.13012000, 384.18024000, **3100 series** (3100, 3102, 3103, 3116 Simple, 3133, 3140)

413K, 413K13, 416K Stylist, 418K Stylist, 419, 4205, 4302, 4305, 4314, 4325, 438K, 4411 Heavy Duty, 4423 Heavy Duty, 4514, 4517, 4522, 457K, 4611, 466K Stylist, 476, 476, 476 Stylist, 477K, 478K, 4814, 4823, 4830, 4830NWC, 4832, 484, 490, 495,4000 series (4000, 4001, 4002, 4003, 4004, 4005, 4006, 4007, 4008, 4009, 4010, 4011, 4012, 4013, 4014, 4015, 4016, 4017, 4018, 4019, 4020, 4022, 4021)

5017, 502, 5028, 5040, 5050, 507, 509, 5102, 5107, 5122, 5123, 5124, 5127, 513 Stylist, 5130, 514, 5140, 5144, 5147, 5160, 5170, 518 Stylist, 5180, 521, 522, 5255, 527, 533 Stylist, 534 Stylist, 535, 538 Stylist, 5405, 543, 5050, 5500 Series, 5502, 5504, 5508, 5522, 5524, 5525, 5528, 5530, 560 Series, 5705, 5710, 5735, 57817C, 57820, 57825C, 5800, 5802, 5805, 5806, 5808, 5810, 5817C, 5818, 5823, 5825, 5828, 5830, 5838

SINGER

SINGER

6011, 6012, 6038, 6100, 6100 Series, 6104, 6105, 6106, 610U, 6110, 6136, 6160, 6180 Brilliance, 6199 Brilliance, 6201, 6202, 6211, 6212, 6215, 6217, 6252, 6305, 6500 Series, 6544 Stylist, 6548 Stylist, 66, 66-1, 66-14, 66-16, 66-18, 66-24, 66-3, 6620

7011, 7015, 7021 Debutante, 7025C, 7258 Stylist, 7300, 7400, 7422 Advance, 7424, 7426, 7430, 7436 Ingenuity, 7440, 7442, 7444, 7446, 7460, 7462, 7462 Touch & Sew, 7464, 7466, **7100 series** (7100, 7106, 7108, 7110, 7174, 7184)

800 Series, 807, 814 Stylist, 8200, 8220, 8222, 8234 Magic, 827, 8280 Prélude, 831, 832, 833 Stylist, 834 Stylist, 842, 843, 8500, 8508, 860, 8600, 8734, 875, 8763 Curvy, 876, 8770 Curvy, 8774, 8780 Curvy, 8784, 8834, **8000 series** (8000, 8002, 8007, 8010, 8014, 8019, 8034)

9002, 9014, 9500 Series, 9600 Series, 9612, 9618, 972, 9800 Series, 99-31, 99K, 9910, 9920, 9960, 9960 Quantum Stylist, CE-100, CE-200, CG 500, CG 550, CG 590, CM17C Craft Mate, DL17C, DSX, HD102, HD105, HD110, SM14C, Sonota, Spartan, XL1 Quantum